

DDR - Dance Dance Revolution System

What is needed?

By Motion Fitness

In order to operate DDR you need the following items:

- 2 Commercial Quality DDR platforms
- Sony PlayStation2
- DDR Software – i.e. DDR MAX2
(we recommend DDR MAX2 for the starter game because it is the most popular)
- Television

In order to have group dance classes or group exercise classes you need the following:

- DDR Group Dance Pads. Set of 6
These turn your 2 DDR platforms into a group activity for 8 people
We have seen that all the kids follow the steps on the screen for the actual players, so while they are waiting in line they are doing the steps and following the music.
These also help to keep the kids in a line for their next turn
A set of 6 is \$295

DDR Group Program:

DDR usage can accommodate 8 players at one time.

2 game users and 6 practice pads – help with quick rotation.

DDR program goes through approximately 30+ songs per hour (max. 40 songs)

Each session includes 2 people that do 2 songs. = 60 song total usage per hour.

(Two people get on the platforms. First person picks a song choice. After the song, the second person picks a song)

Avg. 6 sessions per hour for each person	=	10 people	14 (max)
Avg. 4 sessions per hour for each person	=	15 people	20 (max)
Avg. 3 sessions per hour for each person	=	20 people	26 (max)
Avg. 2 sessions per hour for each person	=	30 people	40 (max)
Avg. 1 session per hour for each person	=	60 people	80 (max)

You can enhance your basic DDR system with:

- Anti-Theft Lock Box. Secure your game console and software. \$249.00
- 50 watt powered speakers. These plug directly into the TV or Playstation and creates an Arcade-like atmosphere. Perfect for larger rooms, and to really hear the bass music notes. \$150

Prices subject to change.

Easy Steps to ordering your complete DDR System

Step 1:

Choose from our selection of Commercial Quality DDR platforms.

- Light Commercial DDR Platform. Our entry level commercial platform
\$999 for 2 platforms
- Competition DDR Platform. Full Commercial – 1 year warranty
\$1,500 for 2 platforms
- Arcade DDR Platform. Full Commercial – 2 year warranty
\$2,590 for 2 platforms
- Tournament DDR Platform. Full Commercial – 4 year warranty
\$3,790 for 2 platforms

Step 2:

Connect DDR Platforms to a Sony PlayStation / PlayStation2, with DDR Software

- Already have your own or will purchase on your own
\$0.00
- Order through Motion Fitness for a turn-key set-up.
PlayStation2 Game Console, Two Memory Cards, DDR MAX2 Game Software,
2 year 100% warranty on Game Console
\$300

Step 3:

Create a group atmosphere for classes, group exercise, large events.

- Do not need
\$0.00
- Order through Motion Fitness
\$295 Set of 6 DDR Group Dance Pads

Step 4:

Popular add-ons to enhance the gaming experience

- Do not need
\$0.00
- Anti-Theft Lock Box – Highly Recommended
\$240
- 50 watt Powered Speakers – Highly Recommended
\$150
- 32" TV. Recommended to have a 32" or larger screen \$400
Plasma, big screens, custom installs available
- Video Cart. Portable unit holds TV, PlayStation, Lock Box, Speakers. \$400

Trademark and copyright names © TM – contact us for licensing opportunities:
Dance Arcade, DDR Arcade, XR Play, XR Zone, XR Arcade, Arcade Express,
Motion 123, Move It Zone